



### Box Contents

- 1 × TWS Earbuds (Left & Right)
- 1 × Charging Case
- 1 × USB Type-C Charging Cable
- 1 × User Manual
- 1 × Warranty card

### Product Overview

FITPRO PRIME True Wireless Earbuds are designed to deliver powerful bass, clear calling, and stable Bluetooth connectivity with a premium design.

Suitable for music, calls, workouts, and daily use.

### Troubleshooting

Earbuds not connecting:  
Turn Bluetooth OFF and ON again  
Remove **"PRIME"** from the device list and re-pair

**One earbud not working:**  
Place both earbuds in the charging case  
Remove and reconnect again

### Technical Specifications

Bluetooth Solution: AB5756C  
Bluetooth Version: 5.4  
Transmission Distance: Up to 15 meters  
Speaker: True Copper Ring RE0032-01  
Charging Port: Type-C  
Frequency Range: 20Hz – 20KHz

Bluetooth Protocols:  
**A2DP / AVCTP / AVDTP / AVRCP / HFP**

### Warranty

Warranty is applicable as per FITPRO brand policy  
Physical damage or water damage is not covered under warranty

Customer Care: **8502809758**  
Email: [Support@fitprolifestyle.com](mailto:Support@fitprolifestyle.com)  
Website: [www.fitprolifestyle.com](http://www.fitprolifestyle.com)



Manufactured in  
**Clubmall internet PVT LTD.**

Country of Origin  
**INDIA**







### Key Features

- Heavy Bass
- HD Call Quality
- Sport Mode Design
- Bluetooth 5.4
- Wireless Distance: Up to 15 meters
- Selfie Control
- Change Voice Function
- Auto Connect

### Battery & Backup

Earphone Battery	Charging Case Battery	Music Play Playback	Shutdown Standby Time
50 mAh	800mAh	72 Hours	150 Days

### Charging Instructions

- Place both earbuds into the charging case
  - Close the charging case properly
  - LED indicator will show charging status
  - Charge the case using the Type-C cable
- Charging Time  
Charging Case: Approx. 150 minutes  
Earbuds: Approx. 55 minutes
- Note: Fully charge the earbuds and charging case before first use.
- 

### Bluetooth Pairing

- Open the charging case
  - Earbuds will power ON automatically
  - Turn ON Bluetooth on your mobile device
  - Select **"PRIME"** from the available device list
  - Once connected, earbuds are ready to use
- Earbuds will auto-connect when the case is opened next time.**
- 

### Calling Function

**Tap the earbud to answer an incoming call**  
**Built-in HD microphone provides clear voice quality**  
**Tap again to end the call**

### Touch / Control Functions

- Single Tap – Play / Pause
  - Double Tap – Answer / End Call
  - Touch Gesture – Volume Control
  - Selfie Control – Camera Shutter
  - Change Voice – Supported
- (Functions may vary depending on device compatibility)
- ### Safety Instructions
- Do not immerse the earbuds in water
  - Avoid exposure to excessive heat
  - Use only the supplied Type-C charging cable
  - Keep out of reach of children