

FITPRO® X FLIP 102

User Manual



Box Contents

- 1 × TWS Earbuds (Left & Right)
- 1 × Charging Case
- 1 × USB Type-C Charging Cable
- 1 × User Manual
- 1 × warranty card

Product Overview

FITPRO X FLIP 102 True Wireless Earbuds are designed to deliver powerful bass, clear calling, and stable Bluetooth connectivity in a compact and stylish design.

Suitable for music, calls, workouts, and daily use.

Troubleshooting

Earbuds not connecting:
Turn Bluetooth OFF and ON again
Remove **"X FLIP 102"** from the device list and re-pair

One earbud not working:
Place both earbuds in the charging case
Remove and reconnect again

Technical Specifications

Bluetooth Solution: AB5756C
Bluetooth Version: 5.4
Transmission Distance: Up to 15 meters
Speaker: True Copper Ring RE0032-01
Charging Port: Type-C
Frequency Range: 20Hz – 20KHz

Bluetooth Protocols:
A2DP / AVCTP / AVDTP / AVRCP / HFP

Warranty

Warranty is applicable as per FITPRO brand policy
Physical damage or water damage is not covered under warranty

Customer Care: **8502809758**
Email: Support@fitprolifestyle.com
Website: www.fitprolifestyle.com



Manufactured in
Clubmall internet PVT LTD.

Country of Origin
INDIA



Key Features

- Heavy Bass
- HD Call Quality
- Sport Mode Design
- Bluetooth 5.4
- Wireless Distance: Up to 15 meters
- Selfie Control
- Change Voice Function
- Auto Connect

Battery & Backup

Earphone Battery	Charging Case Battery	Music Play Playback	Shutdown Standby Time
40 mAh	800mAh	72 Hours	150 Days

Charging Instructions

- Place both earbuds into the charging case
- Close the charging case properly
- LED indicator will show charging status
- Charge the case using the Type-C cable



Charging Time
Charging Case: Approx. 150 minutes
Earbuds: Approx. 55 minutes

Note: Fully charge the earbuds and charging case before first use.

Bluetooth Pairing

- Open the charging case
- Earbuds will power ON automatically
- Turn ON Bluetooth on your mobile device
- Select **"X FLIP 102"** from the available device list
- Once connected, earbuds are ready to use



Earbuds will auto-connect when the case is opened next time.

Calling Function

Tap the earbud to answer an incoming call
Built-in HD microphone provides clear voice quality
Tap again to end the call

Touch / Control Functions

- Single Tap – Play / Pause
- Double Tap – Answer / End Call
- Touch Gesture – Volume Control
- Selfie Control – Camera Shutter
- Change Voice – Supported

(Functions may vary depending on device compatibility)

Safety Instructions

- Do not immerse the earbuds in water
- Avoid exposure to excessive heat
- Use only the supplied Type-C charging cable
- Keep out of reach of children